BABY LOCK SEWING ACCESSORIES

Flex Reaction Foot

(BLQP-FR)

Instructions

This advanced foot is great for creating seams with a topstitch on fabrics that are difficult to feed, like silk, leather, velvet, vinyl, micro fibers and suede. The built-in spring keeps fabric from sliding, giving you great control as you stitch.



INSTRUCTIONS:

- 1. Raise the presser foot and raise the needle to the highest position.
- 2. Loosen and remove screw using the screwdriver included with your machine.
- 3. Attach the Flex Reaction foot and tighten the screw.
- 4. Engage pin feeding according to the thickness of your fabric for easy feeding or otherwise hard to feed fabrics.



